


Harmony Tablet - Quick Start Guide




Updated 21 Feb 2018



Step 1 Power on tablet by pressing and holding the power button until it vibrates. Tablet will then boot up. (Room mic should be securely plugged into tablet's headset jack at all times while tablet is in use but can be unplugged when tablet is not in use.)



Step 2 Pop open kickstand by pushing in the metal button on the back. Position tablet as desired.



Step 3 Sign in by tapping SELECT USER and choosing your user.




Step 4 Power on Bluetooth mic by pressing and holding the ON/OFF button for 3 seconds. (Power off mic in same way.) Mic comes already paired with tablet -- steady blue flashes means mic is synced and can be handed to the instructor/presenter. **For best results, mic should be worn (either clipped onto clothing or onto lanyard).**



BACK


HOME

RECENT
SCREENS




CONNECT WITH CAPTIONER

This is the primary home screen. Follow the on-screen instructions to start audio/video and view live captioning. (After tapping JOIN, *do not* tap back as this exits the call.)



CHAT WITH CAPTIONER / SUPPORT

This is the secondary home screen. To get here, swipe sideways from the primary home screen. Tap the name of the person you want to send a message to. (You can also chat from your own device. Ask us how!)



INCOMING CHATS

There are two ways to handle incoming chats on tablet. See illustration. !



BACK

HOME

RECENT
SCREENS

